



Battery Instruction Guide

Removing and Replacing the Battery

- **Note: The Journey Adventure Scooter battery weighs 20 pounds.**
- **Turn off and disconnect the scooter.**
- **Remove the seat** by lifting it straight upward.
- **Take out the battery compartment** by holding the handle and gently pulling upward.
- **To install a new battery:** place it in the same position as the old one, then return the seat to its original position.



Charging the Battery

- The scooter can be charged in **two ways:**
 - **Using the port on the scooter,** OR
 - **Using the port on the battery pack.**
- Plug the charger first into the scooter or battery pack, then into a wall outlet.
- When the battery is **fully charged**, unplug the charger **from the scooter first, then from the wall outlet.**



Reading the Battery Level

On the scooter's handlebar panel (the tiller), you'll see the battery meter:

- **Green = fully charged**
- **Yellow = battery getting low**
- **Red = needs charging right away**

Safe Use of the Battery

- **Do not use the scooter in small, enclosed spaces** or near open flames.
- **Avoid extreme temperatures.**
 - Below **-40°F** or above **122°F** can damage the battery.
 - If temperatures go above 122°F, a special high-temperature battery is required.
- **Keep away from water.** Do not use or store the scooter where the battery might get wet, as this can cause a short circuit.
- **Do not cover the battery with plastic films or sheets.** This could create static electricity, which may lead to an explosion.

Routine Battery Care

- **Before first use:** Charge the battery for **6–8 hours**.
- The battery's performance improves after about **4–5 full charges**. As you begin using a new battery, it may require 10–20 full charge and discharge cycles to reach peak capacity. Be sure to avoid deep discharges during this time.
- If you're not planning to use your device for some time, fully charge the batteries and top them off every couple of weeks. If you're storing the device long-term, disconnect the batteries.
- To help prolong battery life, avoid letting the battery get below 20–30%.
- Charge batteries nightly or after each use, even if they're not fully drained. This maintains battery health. Don't interrupt battery charging cycles.
- Always charge in a **cool, dry, ventilated space** (5°C–30°C).
 - **Do not charge** in direct sunlight, in the rain, or near heaters or cookers.
- **Stop using the battery immediately** if you notice cracks, leaks, overheating, or strange charging behavior. Contact a professional or the scooter manufacturer for assistance.

Important Safety Warnings

- **Never take the battery apart.** This is dangerous.
- If the battery leaks and liquid touches your **skin, clothes, or eyes:**
 - Wash immediately with lots of water.
 - Seek medical attention right away.
- **Do not throw the battery into water or fire.** This may cause it to explode.
- **Never wash the scooter with water.**
 - If water gets inside, disconnect the power, wipe the scooter dry, and leave it in a ventilated space for at least **24 hours** before using it again.
- **Keep the battery out of reach of children.**